




LEFT TRIGGER

RapidFire Mode 5

RIGHT TRIGGER

RapidFire modes 1-8



SYNC BUTTON

PLAYER 3 LED

Hold down right trigger and tap the sync button to change Special Modes

LED ON Special mode enabled
LED OFF Special mode disabled
BLINKING When changing modes

List of special modes:

- 3-Round burst firing **1**
- 5-Round burst firing **2**
- Akimbo mode **3**

Burst Mode: For single-fire guns.

Akimbo Mode: When the right trigger is pulled, the controller automatically pulls left trigger for you.

PLAYER 4 LED

Hold down left trigger and tap the sync button to toggle RapidFire on and off

LED ON RapidFire enabled
LED OFF RapidFire disabled
BLINKING When changing firing speed

Tap sync to change firing speed:

- 1** World at War
- 2** Modern Warfare 1 (DoubleTap), Left 4 Dead
- 3** Modern Warfare 1 & 2
- 4** Gears of War 1 & 2
- 5** Halo 3 & ODST (Dual wielding)
- 6** Grand Theft Auto IV
- 7** Rainbow Six Vegas 2
- 8** User programmable slot

Thor's Hammer

All-in-one 8-mode Instructions

